

FOAM-TITE

A Polymer-modified, Cementitious Adhesive and Base Coat



Coverage

Foam-Tite as an adhesive:
Approximately 60-90 LFT
per 90-lb bag
Foam-Tite as a coating:
Approximately 1 sq-ft / per dry
pound at 1/8" thickness
Coverage will vary depending
on ambient temperature,
surface temperature, surface
porosity, and/or application
methods.

Packaging

Moisture resistive, 90lb (40.8kg) bags Moisture resistive, 50lb (22.7kg) bags

Storage

- 1. Store bags in a cool, dry location.
- 2. Store away from direct contact with the ground and/or concrete.
- 3. Store out of direct sunlight.
- 4. Protect bags from weather and other damage.

Shelf Life

1 Year

Color

Natural Grey

Product Description

Foam-Tite is a dry blend, polymer-modified, portland cement-based material specifically formulated for coating and attaching architectural EPS foam shapes to approved substrates. May also be used as a leveling coat and as a Crack-Guard System (CGS).

Features	Benefits
Dry Mix	Easy to mix and store; minimal waste
Excellent Workability	Easy and quick to apply
Multiple Formulations	Provides suitable base for various finishes
Economical	Reduced material costs

Basic Uses

Foam-Tite is a base coat and adhesive for attaching and coating architectural foam shapes in residential and commercial applications. It is an excellent material for automated foam coating machines. Foam-Tite may be used in the Superior Stucco Crack Gaurd System and as a leveling coat over approved substrates.

NOTE: Not for use with EIF Systems.

Area of Use

As an adhesive to attach architectural foam shapes to the following substrates:

- 1. Cement backer board
- 2. Masonry
- 3. Poured-in-place and/or tilt-up concrete
- 4. One coat stucco
- 5. Brown coat
- 6. Exterior stucco

As a leveling/skim coat and patching material over:

- 1. One coat stucco
- 2. Brown coat
- 3. Masonry
- 4. Poured-in-place and/or tilt-up concrete

As a base coat over:

I. EPS architectural foam shapes

Application Instructions



Surface Preparation

All surfaces to receive application must be clean and free of debris, dirt, dust, efflorescence, grease, oils, curing agents, and cleaning solutions. Ensure that all surfaces are smooth and free of any irregularities. Repair all cracks with the appropriate patching material for the existing substrate.

Mixing

- ı. Add 3qt (2.8L) of clean, potable water to an empty, 5 gallon pail.
- 2. Add one bag of Foam-Tite to the water while mixing with a Jiffler-type mixer.
- 3. Mix for a minimum of 3 minutes.
- 4. Stop mixing and allow the material to set for 5 minutes.
- 5. Material may be retempered once adding only enough water to reach the desired consistency.

NOTE: Foam-Tite may also be mixed in a paddle type, plaster mixer following the above instructions.

Application

For Use as a Base Coat - Hand Application Method

- I. Using a hawk and trowel apply the Foam-Tite to the receiving surface to a thickness no greater than 1/4" (6.4mm) in a single application.
- 2. Refer to the CG-Mesh Product Data Sheet for mesh application procedures. (See Note 3)
- 3. If desired, apply a second coat of material over the first.
- 4. Float the Foam-Tite to provide a mechanical key for the finish.

For Use as a Base Coat - Machine Sprayed Method

- 1. Add the desired amount of mixed material to the sprayer tank.
- 2. Apply the material to the receiving surface. Avoid puddling.
- 3. Refer to the CG-Mesh Product Data Sheet for mesh application procedures. (See Note 3)
- 4. Apply a second coat of material over that of the first.
- 5. Rod or screed the second coat to a maximum thickness of ı/4" (6.4mm).
- 6. Float the Foam-Tite to provide a mechanical key for the finish.

For Use as an Adhesive

- I. Apply the Foam-Tite to the back of the architectural foam shape with an approved notched trowel.
- 2. Apply the Foam-Tite side of the architectural foam shape to the substrate.
- 3. Ensure that the entire architectural foam shape has been firmly attached to the substrate.

For Use as a Leveling or Patching Coat

- 1. Apply the material to the properly prepared approved substrate. Do not exceed 1/4" thickness in one pass. A second coat can be applied after the first coat has reached its initial cure.
- 2. Application method will vary due to job conditions.

NOTES

- 1. Allow Foam-Tite to set for a minimum of 24-hours prior to working on foam shape.
- 2. When applying Superior Exterior Stucco or other cement-based finishes over Foam-Tite coated foam shapes, the use of a bonding agent or acrylic admix is strongly recommend to ensure proper bond. Over Foam-Tite skim coated walls, the use of a bonding agent or acrylic admix is required when applying Superior Color Coat or other cement-based finishes. The recommended volume of admix is one to two quarts

Disclaimer
Stucco Supply [Manufacturer] MAKES NO
WARRANTY OF MERCHANTABILITY OR
FITNESS FOR A PARTICULAR PURPOSE WITH
RESPECT TO THE PRODUCT(S) SOLD HEREIN.
The recommendations, suggestions,
statements and technical data are based on
the best knowledge available to Manufacturer
and are given for informational purposes ONLY
and without any responsibility for their use. It
is expressly understood and agreed, as a
condition of the use of this product, that the
buyer's sole and exclusive remedy for any
claimed defective product against
Manufacturer shall be the replacement of
products actually proven to be defective.
Handling and use of the products

are beyond the control of Manufacturer; therefore, no warranty is made, expressed or implied, as to the results obtained from the use of the product or against any claims for infringement of patents resulting from use of the product. Under no circumstance shall Manufacturer be liable for incidental or consequential damages arising out of the use or the improper application of the product. Before applying the product, the user shall determine the suitability of the product for his/her independent use, assuming all risks and liability whatsoever in connection therewith. This writing constitutes a complete and exclusive statement of the understanding between Manufacturer and Buyer.

of Foam-Tite or two to three quarts of Superior Admix 2000 per 90-lb sack of Superior Exterior Stucco. Acrylic Bonder or Ultra-Tite 60 are recommended bonders.

3. The use of fiberglass fabric mesh is at the discretion of the architect/builder/contractor. Using mesh will increase impact resistance and may be necessary to properly gauge minimum thickness of the Foam-Tite. Mesh is always recommended in areas of high traffic. A minimum 3/16" (4.8mm) thickness of Foam-Tite is required when mesh is not used.

Curing

Curing and/or drying time may vary due to climatic conditions, but should not take less than 24 hours at an ambient and surface temperature of $70^{\circ}F$ (21°C) and 55% R.H. Variations in ambient and surface temperature and humidity may prolong curing and/or drying time. All freshly applied material must be protected by an approved protective system from inclement weather until fully dry and cured. It is the responsibility of the applicator to determine if the product is fully cured and/or dry prior to exposing it to rain, snow, dew, and/or any other inclement weather condition that may be detrimental to the product.

Limitations

DO NOT apply product when the ambient and surface temperature is below $40^{\circ} F (4^{\circ} C)$.* When hot, dry, or windy conditions exist, protection must be provided. The ambient and surface temperature must maintain the above requirements until fully cured (See CURING). Material that is allowed to freeze may suffer irreparable damage. Protect all work from inclement weather with an approved protective system until fully cured.

DO NOT add any other materials to the mixture of the product without written approval from Stucco Supply.

DO NOT deviate in the mixing or application procedures contained in this, or any other Product Data Sheets, without written approval from Stucco Supply.

DO NOT apply Foam-Tite if there are contaminates on the receiving surface. Contaminates may include, but are not limited to, dust, debris, efflorescence, and/or oils.

DO NOT add any more water than prescribed.

DO NOT saturate the wall during preparation and/or water curing. DO NOT leave Foam-Tite unfinished.

DO NOT use Foam-Tite as a base coat or an adhesive in EIFS applications.

NOTE: Failure to follow manufacturer's written specifications could result in the following, but not limited to spalling, cracking, peeling, chipping, delamination, discoloration, wash off, and overall system failure.

Cleaning

Cleaning may be accomplished with water immediately after use.

Safety

Avoid contact with eyes or prolonged contact with skin. Wash thoroughly after handling. In case of eye contact, flush immediately with running water for at least 15 minutes. Consult a physician immediately. Do not take internally. Be sure to provide adequate ventilation in enclosed areas. Use of an approved respirator is recommended.

KEEP OUT OF REACH OF CHILDREN

Claims
Any Claimant shall notify Manufacturer immediately in writing of any alleged defect in the material. Claimant will provide Manufacturer with a reasonable and exclusive opportunity to investigate and test for the alleged defect. For any olaim that is not valid Claimant agrees to pay Stucco Supply's reasonable charges, including travel and labor associated with investigation of such claim.

Technical Assistance Technical assistance and information is available by calling (408) 292-0454

Warranty
The following is made in lieu of all expressed
and implied rights, warranties and conditions,
statutory or otherwise. The manufacturer's
only obligation shall be to replace such
quantity of products proven to be defective
within one year following the date of
within one year following the date of
manufacture, provided that the ellegt of
manufacturer's plant and is accompanied with
proof of purchase and batch number.