

# **SUPERIOR STUCCO SHOWER FINISH**

**DESCRIPTION:** **SUPERIOR STUCCO SHOWER FINISH** provides a hardy, enduring finish over a typical Scratch & Brown, (a Portland Cement plaster BASE COAT) in shower and bath enclosures, or other wall areas subjected to water exposure.

**COMPOSITION:** **SUPERIOR STUCCO SHOWER FINISH** is scientifically blended at our manufacturing facility and contains Portland cement, Hydrated Lime, Calcium Carbonate and our ***SUPERIOR STUCCO*** proprietary ingredients. Meets or exceeds ASTM C-926 Standards: Portland Cement Type I ASTM C150. Hydrated Lime ASTM C-206. Available in White color finish.

**COVERAGE:** Approximate coverage per 50 lb. bag: SMOOTH finish = 10-12 sq. yards. Coverage will vary depending on substrate, texture and thickness of application.

**PROCEDURE:** The Saturated Surface Dry (SSD) Method is used to equalize absorption of finish material prior to application of the first 'tight' coat used to even suction and prepare for the second Top Coat. Water troweling is required to achieve a smooth, compact, somewhat slick surface.

**MIXING:** Using a mechanical plaster, or drill paddle mixer. Start with clean potable water. Mix for 10-15 minutes to a thin consistency until it is smooth and free of lumps. After 10-15 minutes disengage mixing and let the material take on its' initial "set" (3-5 minutes), then adjust water to desired consistency and only mix long enough to achieve desired material.

**APPLICATION:** **SUPERIOR STUCCO SHOWER FINISH** shall be minimally 1/8" thick. Smooth finish: Trowel apply an even tight coat completely covering the base coat and allow it to set; although prior to drying out, trowel apply a second coat of the same material over the first and water trowel the surface to the desired or approved finish level, using as little water as possible. During hot, dry, weather; a light misting with clean potable water of the dried product is recommended. 28 days is required for proper curing.

**LIMITATIONS:** Do not apply **SUPERIOR STUCCO SHOWER FINISH** when the temperature is below 40 degrees F or above 100 degrees F. This range of temperature must be kept for 48 hours to ensure proper curing. Keep away from hydrostatic pressure (Moisture/water) after applying until dry. Do not apply **SUPERIOR STUCCO SHOWER FINISH** until surface is free of all contaminates. Application in direct sunlight may affect the final outcome and color consistency. Under normal conditions **SUPERIOR STUCCO SHOWER FINISH** provides a uniform white color finish. However, colors may vary due to job, base coat, weather and methods of application beyond the control of ***Stucco Supply.***

## **GUARANTEE**

The above statement, recommendation, suggestions and technical data are based on the best knowledge to ***Stucco Supply*** and is given as information only, without any responsibility for their use. ***Stucco Supply*** makes no warranties or guarantees to this product, either expressed or implied with respect to merchantability or fitness for particular use of said product. Handling and use of product are out of the control of ***Stucco Supply***, so no warranty is given.

**SAN JOSE STUCCO SUPPLY & DRYWALL - FROM START ↔ TO FINISH**

1601 LITTLE ORCHARD STREET, STE. E SAN JOSE, CA 95110  
[WWW.STUCCOSUPPLYCO.COM](http://WWW.STUCCOSUPPLYCO.COM)